

### Presenters



Shelly Sturgis
Strategic Account Manager – New York
Sloan Valve Company
New York City, NY



Sandi Cooper Strategic Account Manager – New England Sloan Valve Company Boston, MA



Kim Darke-Miller Strategic Account Manager - Midwest Sloan Valve Company Chicago, IL



### Agenda

- Learn the steps required to specify a Sloan sink
- 2. Understand how each step or selection impacts the price and lead time of a sink
- 3. Review the language used and how it coordinates in the plumbing schedule
- 4. Get familiar with Sloan's resources: the people and applications that aid in the specifying process

What we won't cover

- 1. Current lead times
- 2. Competitive products





# What Commercial Restroom Sinks Used to Look Like...













## What's Changed...

### **Contractor's punch list**




### **Architect's vision**





# The Sink Pricing Process... What can go Wrong?




### Where things tend to get held up:

- There's a lack of collaboration
- All details aren't communicated at the onset
- Budget is unclear and design intent is lost


Designer and Sloan SAM or A&D Rep coordination between Steps 1 & 2 is most critical for success











Link to Sloan Sink Selector
















### 1. Select Sink Design

# This is when you want to decide the following...

- Material
- Dimensions
- # of stations







- Power Supply Battery, Hardwired, or Hybrid?
- Faucet Model <u>Link to Sloan Faucet Selector</u>
- Soap Dispenser Model <u>Link to Sloan Soap Selector</u>
- Deck Mounted Hand Dryer Model <u>Link to AER DEC</u>
- Finish Chrome or Special PVD <u>Link to Finishes</u>















### 2. Select Fittings









- Paper Towel Holder Model
- Trash Openings
- Baby Changing Station
- Bag Hooks
- Wall Mounted Hand Dryer Model
- LED Lights

















### 3. Select Accessories









- Cabinet Style
- Angled Stainless Steel
- Vertical Stainless Steel
- Angle Brackets
- Clad Material
- Hook and Hang
















### 4. Select Enclosure












- Reach out to SAM or A&D Rep
- SAM or A&D Rep to complete Architectural Worksheet
- Request budget quote & drawings
- Review budget together
- Sign-off on approved drawings








### 5. Request Quote



Reach out to SAM or A&D Rep



SAM or A&D Rep to Complete Architectural Worksheet



Request Budget Quote & Drawings



Review Budget Quote together



Sign-off on Approved Drawings



 Reach out to SAM or A&D Rep **FINISH** 5. • SAM or A&D Rep to complete Architectural Worksheet Request budget quote & drawings Request Review budget together Quote Sign-off on approved drawings Cabinet Style Angled Stainless Steel Vertical Stainless Steel Select Enclosure Angle Brackets Clad Material Paper Towel Holder Model Trash Openings Baby Changing Station Select Accessories Bag Hooks Wall Mounted Hand Dryer Model • Power Supply – Battery, Hardwired or Hybrid? Faucet Model Soap Dispenser Model Select Fittings Deck Mounted Hand Dryer Model • Finish – Chrome or Special PVD Deck - Undermount or Vessel? • # of Stations – Standard or Custom? Basin – Trough or Individual? Select Sink Design Material – Corian or Quartz? Dimension





### **Three Critical Items to Quote**

### What needs to be communicated

- What are the overall dimensions? Straight size vs custom
- What is the material and material color?
   We can wait on color but not material
- What mounting type?

### What we usually see

|             | PLUMBING FIX                        | PLUMBING FIXTURE SCHEDULE |  |  |  |
|-------------|-------------------------------------|---------------------------|--|--|--|
| Type Mark   | DESCRIPTION                         | Manufacturer              |  |  |  |
| RESTROOM PL | ÚMBING FIXTURE                      | 6911                      |  |  |  |
| DF          | EZHZO INWALL DOTTLE FILLING STATION | Elkay Manufacturing       |  |  |  |
| 0           | DESIGNER SERIES SINK DSG-81000      | SLOAN                     |  |  |  |
| FL1         | ECOS SENSOR FLUSHOMETER             | SLOAN                     |  |  |  |
| FL2         | ECOS SENSOR FLUSHOMETER             | SLOAN                     |  |  |  |
| FSD         | FAUCET & SOAP COMBO                 | SLOAN                     |  |  |  |
| LA          | OVAL UNDERMOUNT LAVATORY            | SLOAN                     |  |  |  |
| UR          | SMALL WASHDOWN URINAL               | SLOAN                     |  |  |  |
| wc          | ELONGATED WALL-MOUNTED WATER CLOSET | SLOAN                     |  |  |  |
|             |                                     |                           |  |  |  |



### List Your Rep's Name...

Your local SAM or A&D reps name and number will help expedite the process

| PLUMBING FIXTURE SCHEDULE |                                      |                     |                                     |  |  |  |
|---------------------------|--------------------------------------|---------------------|-------------------------------------|--|--|--|
| Type Mark                 | DESCRIPTION                          | Manufacturer        | Model                               | COMMENTS   |  |  |
| RESTROOM PL               | UMBING FIXTURE                       | 43                  | 1.0                                 |  |  |  |
| DF                        | EZH20 IN-WALL BOTTLE FILLING STATION | Elkay Manufacturing | LZWS8K                              |  |  |  |
| FC                        | DESIGNER SERIES SINK DSG-81000       | SLOAN               | DSG-81000                           |  |  |  |
| FL1                       | ECOS SENSOR FLUSHOMETER              | SLOAN               | ECOS<br>8111-1.28-OR                |  |  |  |
| FL2                       | ECOS SENSOR FLUSHOMETER              | SLOAN               | ECOS<br>8186-0.125-1-IN-ST<br>OP-OR |  |  |  |
| FSD                       | FAUCET & SOAP COMBO                  | SLOAN               | ESD-2001-CP                         |  |  |  |
| LA                        | OVAL UNDERMOUNT LAVATORY             | SLOAN               | SS-3001                             |  |  |  |
| UR                        | SMALL WASHDOWN URINAL                | SLOAN               | SU-7009-CO                          | 3<br>U.  |  |  |
| WC                        | ELONGATED WALL-MOUNTED WATER CLOSET  | SLOAN               | ST-2459                             | BEMIS COMMERCIAL PLASTIC<br>ELONGATED TOILET SEAT MODEL<br>#1955CT |  |  |



## Spec Language

- DSG 8X X = the number of stations you want
  - Choose as many stations as you want
- Choose Corian or quartz
  - Default is Corian
- Choose angle bracket or enclosure
  - Default is stainless steel enclosure



DESIGNER SERIES™ SINK DSG-84000

### DESCRIPTION

Designer Series™ 4-Station Wall-Mounted Gradient Sink.

- · Material: Corian/Silestone
- Width: 120" (3,048mm)

### **FEATURES**

Four Station Lavatory System with the following features:

- Dimensions: 120" x 22" x 5"
- A monolithic console available in Corian or quartz
- ADA compliant if Installed properly
- · Multiple mounting options
- Basins can be sized to project requirements
- . Many customization options see architectural worksheet for all
- · Easy installation
- · Pairs great with Sloan faucets and soap dispensers

- · For a complete list of Corian® colors: http://www.corian.com/-colors-of-corian-r-
- For a complete list of Corian® guartz colors: http://www.corianguartz.com/-colors-of-zodiag-r-
- For a complete list of Silestone® guartz colors: http://www.silestoneusa.com/colors/

### SUGGESTED FAUCETS

This sink is compatible with BASYS® faucets.

### COMPLIANCES & CERTIFICATIONS







Sloan Designer Series Sink model no. DSG 8X000 Gradient Style Sink. Product to be fabricated out of Corian or quartz. Sloan automated sensor faucet. Sloan sensor operated foam soap dispenser. Sink design to be ADA compliant and IAPMO certified. Supplied with angle brackets or enclosure

- DSG-80000

ation contained within this document subject to without notice.

customization options - see architectural worksheet for

ind a compatible faucet for this sink. Find a matching soap dispenser for this sink.

### RECOMMENDED SPECIFICATION

Sloan Designer Series Sink model no. DSG 8X000 Gradient Style Sink. Product to be fabricated out of Corian or quartz. Sloan automated sensor faucet. Sloan sensor operated foam soap dispenser. Sink design to be ADA compliant and IAPMO certified. Supplied with angle brackets or enclosure.





# Sink Delivery Path









Postinstallation

**Place Order** 







### More Support from Sloan



SAM - Direct Sloan Rep



A&D Rep. State Specific



Online Resources at Sloan.com



**Tech Support** 



### Sloan Strategic Account Managers (SAMs)



Sandi Cooper – Boston Mobile: +1 781.704.5587 Sandi.Cooper@sloan.com



Kim Darke-Miller – Chicago Mobile: +1 773.216.0003 Kim.Darke@sloan.com



Jeff Gilmore – Director Mobile: +1 224.374.5323 Jeff.Gilmore@sloan.com



Kirk Gruben – Dallas Mobile: +1 512.658.7459 Kirk.Gruben@sloan.com



Teresa Middleton – San Francisco Mobile: +1 224.563.9196 Teresa.Middleton@sloan.com



Mary Phelps – Houston Mobile: +1 832.720.4876 Mary.Phelps@sloan.com



Shelly Sturgis – New York Mobile: +1 732.535.4940 Shelly.Sturgis@sloan.com



Gina Wilkins – Los Angeles Mobile: +1 213.670.3024 Gina.Wilkins@sloan.com



# Find your local Sloan representative for more information

### Sloan Rep Locator tool

- Local code knowledge
- Familiarity with existing sites
- Product knowledge
- Available for onsite consultation

### **Sloan Customer Care Center**

Phone: 800.982.5839

Hours: 7:00 AM - 5:00 PM (CST) Monday – Friday

customer.service@sloan.com

### **Sloan Technical Support**

P: 888.756.2614 F: 800.737.3061

techsupport@sloan.com










J.B. O'Connor Co. – Pittsburgh, PA USA



### Summary

Working with your SAM or A&D Rep

- Streamlines the specification process
- Ensures design intent is realized
- Keeps project on budget





# Questions?



## **Upcoming Sloan Training Webinar**



August 27<sup>th</sup>, 2020

Water Conservation and Sloan Commercial Restroom Products



# Training Comments, Questions, or Suggestions?

Andrew Warnes
Manager – Technical Training
Sloan Valve Company
10500 Seymour Avenue
Franklin Park, IL USA 60131-1259

Office: +1-800-982-5839

E-mail: training@sloan.com

Web: sloan.com

