

#### **CODE NUMBER**

3070061

#### **DESCRIPTION**

1.6 gpf, XL Sweat Solder Adapter Kit, Polished Chrome Finish, 1.5" Flush Connection, Fixture Connection Top Spud, Single Flush, 1" Inlet, 1" Control Stop, True Mechanical Override, Battery, Infrared, GEM-2® Exposed Sensor Water Closet Flushometer.

#### **DETAILS**

Flush Volume: 1.6 gpf (6.0 Lpf)Finish: Polished Chrome (CP)

Power Type: BatteryValve: Piston

• Valve Body Material: Semi-red Brass

Fixture Type: Water ClosetFixture Connection: Top Spud

• Rough-In Dimension: 11 ½" (292mm)

Spud Coupling: 1 ½" (38mm)
Supply Pipe: 1" (25mm)

• Override: True Mechanical (TMO)

Control Stop: 1"Inlet: 1"

• Flush Connection: 1.5"

• Adapter: XL Sweat Solder Adapter Kit (XL)

### **FEATURES**

• Fixed Volume Piston with Filtered O-ring Bypass

• "Low Battery" Flashing LED

• "User in View" Flashing LED

• No External Volume Adjustment to Ensure Water Conservation

True Mechanical Override Flush Button

• 72-Hour Sentinel Flush

Sweat Solder Adapter w/Cover Tube and Cast Wall Flange with Set Screw

- Packing, Stop Seat and Vacuum Breaker Molded from PERMEX® Rubber Compound fChloramine resistance
- Four (4) Size C batteries included
- 1" I.P.S. Screwdriver Bak-Chek® Angle Stop with Free Spinning Vandal Resistant Stop Cap



### **COMPLIANCES & CERTIFICATIONS**









(ADA Compliant, BAA Compliant, BABAA Compliant, cUPC Certified)

#### RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

### **ELECTRICAL SPECIFICATIONS**

• Arming Delay: 10 seconds

• Sensor Range: 22"-42" (559-1,067mm)

## **VALVE OPERATING PRESSURE (FLOWING)**

15-80 PSI (103-552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

## **DOWNLOADS**

- GEM/GEM 2 Piston Type Exposed Installation Instructions
- EBV-500/550-A Installation Instructions
- EL-700/750-A Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Gem 2 Repair and Maintenance Guide
- EBV500/EBV550 Repair and Maintenance Guide
- Additional Downloads

### NOTES

All information contained within this document subject to change without notice.

Looking for other variations of the GEM-2 111 SFSM product? View the general spec sheet with all options.

# WARRANTY

**View Warranty Information** 

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com



# **ROUGH-IN**



